

Eastman Performance Films, LLC

Exterior Film Cleaning and Maintenance Guidelines

Exterior Films are constructed with a proprietary protective weatherable layer that easily sheds dirt particles in normal wind and rain and is designed to withstand weathering through the applicable limited warranty period so minimal cleaning should be needed.

1. Cleaning Step by Step Instructions

- a. If a pane does need cleaning, spray with mild soapy water under minimal to moderate pressure and rinse with clean water.
- b. Spray again with soapy water and rub the surface lightly with a soft wet soapy sponge.
- c. Rinse with clear water under minimal to moderate pressure.
- d. Use a clean, soft rubber squeegee to dry if desired.

2. Important

- Avoid metal object contact with film surface.
- Do not use motorized pressure sprayer equipment or water under greater pressure than household water pressure.
- Avoid cleaning solutions with ketones such as methyl ethyl ketone (MEK) or acetone.
- Do not use standard window washing tools like brushes, paper towels or abrasives.
- In extreme conditions, a soft paint roller can be soaked in lukewarm soapy water, and gently rolled over film surface, to soften and dislodge hard-to-remove dirt. This will help prevent scratching the film surface.

Eastman Performance Films, LLC requires keeping a signed copy of this document for warranty purposes.

Installation date: _____

Customer / Facilities/maintenance Department

Name:

Signature and Company Stamp:

Installation completed by:

Name:

Signature and Company Stamp:
